A

A/C system 13A-871
ABS
Actuator Test 35B-164
Circuit Diagram 90-204
ECU, Check at Terminal 35B-165
Accelerator Pedal 17-8
Adhesive
Body 42A-178
Body 42A-171
Body 42A-12
Body 42A-24
CVT Overhaul 23B-6
Engine 11A-4
Engine Cooling 14-3
Engine Lubrication 12-3
Engine Overhaul 11B-7
Exterior 51-2
Manual Transaxle Overhaul 22B-4
MFI 13A-7
Steering 37-3
Adhesive Table 00-69
Aero Parts 51-2
Air Bag Module
Disposal Procedures 52B-393
Air Bag Module(s) 52B-367
Air Cleaner 15-4
Air Cleaner Element
Replace 00-56
Air Conditioning
Actuator Test 55A-107
Actuator Test 55B-20
Automatic, Circuit Diagram 90-146
Charging 55A-113
Compressor Drive Belt Adjustment 55A-113
Compressor Noise Check 55A-116
Condenser 55A-133
ECU Terminal Check 55A-108
ECU Terminal Check 55B-21
Idle-up Operation Check 55A-117
Outside Air Temperature Sensor 55A-126
Performance Test 55A-114
Power Relay Check 55A-116
Refrigerant Leak Repair 55A-115
Refrigerant Line 55A-134
Sensors (Full-auto A/C) 55B-25
Sight Glass Refrigerant Level Test 55A-112
Air Purifier Filter
Replace 00-68
Amplifier 54A-438
Anti-Lock Braking System (ABS)
Diagnosis 35B-5
Audio System
Circuit Diagram
VEHICLES WITH AUDIO AMPLIFIER 90-174
VEHICLES WITHOUT AUDIO AMPLIFIER 90-168
Auto Adjuster
Function Check
Vehicles with rear drum brake 35A-33
Auto-cruise Control 17-69
Auto-cruise Control 17-9
Auto-cruise Control Switch
Check 17-64
Auto-cruise Control System
Check at ECU Terminal 17-60
Circuit Diagram 90-226
Component Check 17-67
Diagnosis 17-10
Automatic Transaxle
Fluid Level Check 00-62
Automatic Transaxle Fluid
Level Check 00-62
Auto-tensioner
Check 11A-9

B

Backup Light
Circuit Diagram 90-100
Ball Joint Dust Cover
Inspection 34-21
Inspection 33-9
Replacement 33-16
Stabilizer Link, Inspection 34-21
Ball Joint Dust Cover Inspection
Steering 37-20
Ball Joint Seals
Check 00-67
Basic Brake System
Diagnosis 35A-7
Battery 54A-8
Battery
Charging 54A-6
Check 54A-5
Handling 00E-12
Remedy for a Discharged Battery 35B-170
Test 54A-6
Belt
Water Pump and Generator Drive Belt Check 00-59
Bleeding
Brakes (Basic) 35A-25
Power Steering 37-17
Body
Adhesive 42A-178
Adhesive 42A-171
Adhesive 42A-24
Adhesive 42A-12
Sealant 42A-24
Sealant 42A-178
Sealant 42A-171
Sealant 42A-12
Boots
Driveshaft, Check 00-67
Brake Booster 35A-36
Brake Booster
Operating Check 35A-21
Removal and Installation 35A-36
Brake Disc
Pad Wear Check 00-66
Brake Drum
Inside Diameter, Check
Vehicles with rear drum brake 35A-32
Brake Fluid Level Sensor Check 35A-26
Brake Hoses
Check 00-67
Brake Lining
Thickness, Check
Vehicles with rear drum brake 35A-32
Brake Lining and Brake Drum
Contact, Check
Vehicles with rear drum brake 35A-32
Brake Pad
Wear Check 00-66
Brake Pedal 35A-34
Brake Pedal
Check and Adjustment 35A-19
Brake Rotor
Disc, Check 35A-29

Brake Stoplight Switch Check 35A-35
Brake Warning Light
Circuit Diagram 90-106
Bumper
Rear 51-6

C

Camshaft 11B-39
Camshaft 11A-22
Camshaft Position Sensor 16-40
Camshaft Position Sensor 16-40
Camshaft Position Sensor
Check 16-38
Canister
Evaporative Emission 17-87
Evaporative Emission 17-87
Caution Labels 55A-5
Centermember 32-7
Central Door Locking System
Circuit Diagram
VEHICLES WITH KEYLESS ENTRY SYSTEM 90-128
VEHICLES WITHOUT KEYLESS ENTRY SYSTEM 90-122
Diagnosis 42A-31
Centralized Junction
Circuit Diagram 90-19
Charging System 16-2
Charging System
Circuit Diagram 90-40
Diagnosis 16-3
Check Valve
Operating Check 35A-24
Cigarette Lighter 54A-224
Clearance Around Hood
Adjustment 42A-5
Clock
Circuit Diagram 90-184
Clock Spring 52B-367
Clutch 21B-3
Clutch
Inspection 21B-5
Clutch Bleeding 21A-3
Clutch Control 21A-6
Clutch Control
Inspection 21A-7
Clutch Housing 22B-37
Clutch Housing
Disassembly and Assembly 22B-37
Clutch Pedal
Check and Adjustment 21A-2
Compression Pressure
Check 11A-16
Compressor (A/C)
Noise Check 55A-116
Compressor Assembly 55A-128
Connecting Rod
Overhaul 11B-59
Connector Inspection 00E-2
Control link 34-8
Control Unit Location 70-2
Controller Area Network (CAN)
Circuit Diagram 90-264
Coolant
Engine, Change 00-65
Coolant Hoses
Heater Hose Inspect 00-66
Radiator Hose Inspect 00-66
Cooling System
Circuit Diagram 90-56
Crank angle Sensor 16-41
Crankcase Ventilation System
Check 17-75
Crankshaft
Overhaul 11B-68
Crankshaft Oil Seal 11A-49
Crankshaft Position Sensor
Check 17-80
Check 17-84
Crankshaft Pulley 11A-19
Crossmember 32-9
Crossmember 34-22
CVT Overhaul
Adhesive 23B-6
Sealant 23B-6
Cylinder Block
Overhaul 11B-68
Cylinder Head
Overhaul 11B-45
Cylinder Head Gasket 11A-53

D

Diagnosis
Anti-Lock Braking System (ABS) 35B-5
Auto-cruise Control System 17-10
Basic Brake System 35A-7
Central Door Locking System 42A-31
Charging System 16-3
Door 42A-131
Emission Control System 17-70
Engine 11A-3
Engine Control System 17-3
Engine Cooling 14-3
Front Axle 26-3
Front Suspension 33-4
Fuel Supply 13B-2
Heated Door Mirror 51-59
Hood 42A-4
Intake and Exhaust 15-2
Manual Transaxle 22A-4
Multiport Fuel Injection (MFI) 13A-10
Parking Brake 36-3
Power Steering 37-4
Power Window 42A-49
Rear Axle 27-2
Rear Suspension 34-4
SRS Air Bag 52B-27
Starting System 16-24
Sunroof 42A-179
Tire 31-2
Tire 31-2
Trouble Code, ABS 35B-6
Trunk Lid 42A-171
Wheel 31-2
Wheel 31-2
Window Glass 42A-14
Windshield Washer 51-21
Windshield Wiper 51-21
Differential 22B-46
Disc Brake
Pad Wear Check 00-66
Disc Brake Assembly
Front 35A-39
Rear
Vehicles with rear disc brake 35A-47
Disc Brake Pad
Check and Adjustment 35A-26
Disc Brake Rotor
Check 35A-29
Door 42A-24

Door 42A-148
Door
Diagnosis 42A-131
Front and Rear, Fit Adjustment 42A-138
Glass and Regulator 42A-151
Handle and Latch 42A-157
Inside Handle Play Adjustment 42A-146
Mirror 51-69
Mirror 51-59
Opening Weather-strip 42A-164
Outside Handle Play Adjustment 42A-145
Switch Check 42A-150
Door Ajar Warning Tone Alarm
Circuit Diagram 90-244
Door Sash Tape 51-8
Door Trim 52A-13
Door Trim
Removal and Installation 52A-13
Drive Belt
Power Steering, Tension Check 37-16
Tension Check and Adjustment 11A-9
Water Pump and Generator Drive Belt Check 00-59
Drive Plate
Overhaul 11B-68
Driveshaft
Front Axle 26-17
Driveshaft Boots
Check 00-67
Drum
Inspection 36-17
Ducts 55A-136

E

EBJ Boot
Replacement 26-25
ECU Terminal
Check 42A-210
EGR System 17-81
EGR System 17-81
EGR Valve
Check 17-82
Check 13A-944
Cleaning 17-84
Electrical System
Check 00E-13
Element, Air Cleaner
Replace 00-56
Emission Control System
Diagnosis 17-70
Emission Control System, Evaporative
Check for Clogging 00-56
Check for Leaks 00-56
Engine
Adhesive 11A-4
Assembly 11A-74
Auto-tensioner 11A-9
Compression Pressure 11A-16
Crankshaft Oil Seal 11A-49
Cylinder Head Gasket 11A-53
Diagnosis 11A-3
Drive Belt 11A-9
Idle Mixture 11A-14
Idle Speed 11A-13
Ignition Timing 11A-11
Manifold Vacuum 11A-17
Sealant 11A-4
Engine Control 17-3
Engine Control Module 13A-952
Engine Control System
Diagnosis 17-3
Engine Coolant
Change 00-65
Concentration Check 14-14
Leak Check 14-12
Replacement 14-13
Engine Coolant Temperature Sensor
Check 17-80
Check 17-84
Check 13A-937
Engine Cooling
Adhesive 14-3
Diagnosis 14-3
Sealant 14-3
Engine Lubrication
Adhesive 12-3
Sealant 12-3
Engine Mounting 32-3
Engine Oil
Change 00-60
Check 12-4
Replacement 12-4
Engine Oil Control Valve
Check 13A-943
Engine Oil Filter
Change 00-61
Replacement 12-5
Engine Oil Pressure
Check 12-6
Engine Overhaul
Adhesive 11B-7
Sealant 11B-7
Tightening Specification(s) 11B-4
Engine Roll Stopper 32-7
Evaporative Emission Canister 17-87
Evaporative Emission Canister 17-87
Evaporative Emission Canister
Inspection 17-88
Evaporative Emission Control System 17-76
Evaporative Emission Control System 17-76
Evaporative Emission Control System
Check for Clogging 00-56
Check for Leaks 00-56
Purge Solenoid Check 17-79
Evaporative Emission Purge Solenoid
Check 13A-944
Evaporative Emission Ventilation Solenoid
Check 13A-944
Exhaust Manifold 15-9
Exhaust Manifold
Overhaul 11B-21
Exhaust Pipe 15-12
Exhaust System
Check 00-60
Exterior
Adhesive 51-2
Sealant 51-2

F

Fan Control Relay
  Continuity Check 14-15
Fastener Tightening Specification(s) 34-2
Fender 42A-8
Filter
  Air Purifier, Replace 00-68
  Engine Oil, Change 00-61
Floor Console 52A-8
Fluid
  Automatic Transaxle, Fluid Level Check 00-62
Flywheel
  Overhaul 11B-68
Fog Light
  Circuit Diagram 90-78
Forward Clutch 23B-57
Forward Clutch 23B-57
Front Axle
  Diagnosis 26-3
  Driveshaft 26-17
  Hub 26-9
Front Axle Hub Assembly 26-9
Front Axle Hub Assembly
  Disassembly and Assembly 26-13
  Inspection 26-12
Front Impact Sensors 52B-361
Front Seat 52A-17
Front Seat Belt 52A-28
Front Suspension
  Diagnosis 33-4
Front Wheel Alignment
  Check and Adjustment 33-8
Fuel Filler Lid 42A-10
Fuel Gauge Unit
  Check 13B-6
Fuel Hose
  Check for Condition 00-56
Fuel Pipe
  Check for Leaks 00-56
Fuel Pressure Test 13A-929
Fuel Pump
  Connector Disconnection 13A-932
  Operation Check 13B-6
  Operation Check 13A-932
Fuel Pump Module
  Replacement 13B-6
Fuel Pump Relay
  Continuity Check 13A-935
Fuel Pump System 13A-848
Fuel Supply
  Diagnosis 13B-2
Fuel System
  Check for Leaks 00-56
Fuel Tank 13B-9
Fuel Tank
  Check for Leaks 00-56
Fuel Tank Filler Tube
  Check for Leaks 00-56
Fuel Tank Pressure Relief Valve 17-87
Fuel Tank Pressure Relief Valve 17-87
Fuel Tank Pressure Relief Valve
  Inspection 17-88
Fuel Warning Light
  Circuit Diagram 90-106
Fuse
  Check 00E-9
Fuses Location 70-12
Fusible Links Location 70-12

G

Garnishes 51-7
Gauge
  Circuit Diagram 90-102
Generator 11B-10
Generator
  Assembly 16-14
  Output Current Test 16-8
  Output Line Voltage Drop Test 16-7
  Regulated Voltage Test 16-10
Glass Sliding Mechanism
  Check and Adjustment 42A-142
Ground Location 70-18
Grounding Location 70-13

H

Hazard Warning Light
  Circuit Diagram 90-94
Headlight
  Circuit Diagram 90-70
Headlining 52A-15
Heated Door Mirror
  Circuit Diagram 90-164
  Diagnosis 51-59
Heated Seat
  Circuit Diagram 90-234
Heater Control Unit 55A-118
Hood 42A-7
Hood 42A-4
Hood
  Diagnosis 42A-4
  Height Adjustment 42A-6
Hood Latch and Striker
  Alignment 42A-5
Horn
  Circuit Diagram 90-99
Hose
  Vacuum, Routing 17-72
Hoses
  Brake, Check 00-67
Hub
  Front Axle 26-9
  Rear Axle 27-7
Hub Bolt
  Replacement 26-8
  Replacement 27-6
Hydraulic Unit 35B-175
Hydraulic Unit Check
  ABS 35B-168

I

Idle Mixture
Check 11A-14
Idle Speed
Check 11A-13
Ignition Circuit System 13A-866
Ignition Coil 16-39
Ignition Coil
Check 16-36
Ignition Key Reminder Warning Buzzer
Circuit Diagram
VEHICLES WITH KOS 90-240
VEHICLES WITHOUT KOS 90-238
Ignition Switch 54A-9
Ignition System 16-34
Ignition System 11B-10
Ignition system
CVT 13A-860
M/T 13A-854
Ignition System
Circuit Diagram 90-36
Ignition Timing
Check 11A-11
Immobilizer System
Circuit Diagram 90-222
Injector 13A-945
Injector
Check 13A-942
Input Shaft 22B-25
Inside Rear View Mirror 52A-17
Inspection Terminal Location 70-17
Instrument Panel 52A-2
Instrument Panel Inspection 00E-8
Intake Air Temperature Sensor
Check 17-84
Check 17-79
Check 13A-936
Intake and Exhaust
Diagnosis 15-2
Intake Manifold 15-5
INVECS-III CVT
Circuit Diagram 90-60

J

Joint Connector 90-14

K

Knock Sensor 16-42
Knock Sensor
Check 16-35

L

Loose Panel 42A-221
Lower Arm 33-15
Lower Arm 34-8
Lower Arm
Inspection 33-16
Lower Arm Ball Joint
End Play Check 33-9
Lower Arm Bushing
Replacement 33-17
Replacement 34-10

M

Main Muffler 15-12
Maintenance
Air Cleaner Element 00-56
Automatic Transaxle Fluid 00-62
Ball Joint and Steering Linkage Seals 00-67
Brake Hoses 00-67
Disc Brake Pads 00-66
Drive Belt 00-59
Driveshaft Boots 00-67
Electrical System 00E-13
Engine Coolant 00-65
Engine Oil 00-60
Engine Oil Filter 00-61
Evaporative Emission Control System 00-56
Exhaust System 00-60
Fuel Hose 00-56
Fuel System 00-56
Spark Plug 00-57
Manifold Absolute Pressure Sensor
Check 17-84
Check 17-80
Manifold Vacuum
Check 11A-17
Manual A/C
Diagnosis 55A-5
Manual Transaxle
Diagnosis 22A-4
Manual Transaxle (Transmission)
Oil Level Check 00-62
Manual Transaxle Overhaul
Adhesive 22B-4
Sealant 22B-4
Mark 51-56
Mass Airflow Sensor
Check 17-79
Check 17-84
Master Cylinder 35A-36
Master Cylinder
Function Check 35A-34
Master Cylinder Assembly 35A-36
Meter
Circuit Diagram 90-102
MFI
Adhesive 13A-7
Sealant 13A-7
MFI System
Circuit Diagram 90-44
Mirror
Door 51-59
Door 51-69
Remote Controlled, Circuit Diagram 90-166
Mitsubishi Multi Communication System (MMCS)
Circuit Diagram 90-186
MMCS 54A-309
Moldings 51-7
Motor 55A-124
Motor 55A-124
Mounting
Engine 32-3
Transaxle 32-5
Multiport Fuel Injection
Diagnosis 13A-10
Multiport Fuel Injection Relay
Continuity Check 13A-934

O

Oil
  Engine, Change 00-60
  Engine, Check 12-4
  Engine, Replacement 12-4
Oil Filter
  Engine, Replacement 12-5
Oil Pan 11A-45
Oil Pan
  Inspection 11A-48
Oil Pressure
  Engine, Check 12-6
Oil Pressure Warning Light
  Circuit Diagram 90-106
Oil Pump
  Power Steering 37-35
  Power Steering, Pressure Test 37-18
Oil Seal
  Crankshaft 11A-49
Other Parts 55B-26
Output Shaft 22B-29
Outside Air Temperature Sensor 55A-126
Oxygen Sensor
  Check 13A-937

P

Parking Brake
  Cable 36-13
  Diagnosis 36-3
  Lever 36-12
  Lever Stroke Check and Adjustment 36-10
  Lining and Drum
    Vehicles with rear disc brake 36-15
  Switch Check 36-11
Parking Brake Lining
  Inspection 36-17
PCV (Positive Crankcase Ventilation) System 17-74
PCV (Positive Crankcase Ventilation) System 17-74
PCV (Positive Crankcase Ventilation) System
  Valve Check 17-75
Piston
  Overhaul 11B-59
Power Distribution System
  Circuit Diagram 90-26
Power Steering
  Bleeding 37-17
  Diagnosis 37-4
  Drive Belt Tension Check 37-16
  Fluid Level Check 37-16
  Fluid Replacement 37-17
  Hoses 37-37
  Oil Pump Assembly 37-35
  Oil Pump Pressure Test 37-18
  Pressure Switch Check 37-19
Power Steering Diagnosis 37-4
Power Steering Gear Box 37-29
Power Steering Linkage 37-29
Power Steering Oil Pump Assembly
  Inspection 37-36
Power Window
  Check 42A-142
  Circuit Diagram
    VEHICLES WITH CENTRAL DOOR LOCKING SYSTEM 90-116
    VEHICLES WITHOUT CENTRAL DOOR LOCKING SYSTEM 90-110
  Diagnosis 42A-49
  Operating Current Check 42A-143
  Timer Function Check 42A-143
Proportioning Valve
  Function Test
    Vehicles without ABS 35A-24
Protector Film
  Vehicles without side air dam 42A-169
Purge Control System
  Check 17-78

R

Radiator 14-26
Radiator Cap
  Pressure Check 14-13
Rear Axle
  Diagnosis 27-2
  Hub 27-7
  Wheel Bearing End Play Check 27-5
Rear Drum Brake
  Vehicles with rear drum brake 35A-54
Rear Drum Brake Linings
  Wear and Leaks Check 00-66
Rear Drum Brake Wheel Cylinder Assembly
  Disassembly and Assembly 35A-56
Rear Hub Rotary-Sliding Resistance
  Check 27-5
Rear Seat 52A-23
Rear Seat Belt 52A-31
Rear Spoiler 51-15
Rear Suspension
  Diagnosis 34-4
Rear Suspension Crossmember 34-22
Rear Wheel Alignment
  Check and Adjustment 34-7
Rear Wheel Cylinder
  Wear and Leaks Check 00-66
Rear Window Defogger
  Circuit Diagram 90-160
Rear Window Glass 42A-20
Relay
  Check 00E-11
Relay Location 70-16
Revolution Pickup Sensor 55A-126
Roof Lid Glass
  Operation Check 42A-214

S

Sealant
  Body 42A-171
  Body 42A-12
  Body 42A-24
  Body 42A-178
  CVT Overhaul 23B-6
  Engine 11A-4
  Engine Cooling 14-3
  Engine Lubrication 12-3
  Engine Overhaul 11B-7
  Exterior 51-2
  Manual Transaxle Overhaul 22B-4
  MFI 13A-7
  Steering 37-3
Sealant Table 00-69
Seat Belt Pre-Tensioner
  Disposal Procedures 52B-393
Seat Belt Tone Alarm
  Circuit Diagram 90-248
Seat Belts With Pre-Tensioner 52B-389
Seat Belts With Pre-Tensioner
  Check 52B-392
Select Lever 22B-35

Sensor
Camshaft Position 16-40
Camshaft Position 16-40
Camshaft Position, Check 16-38
Crankangle 16-41
Crankangle, Check 16-38
Crankshaft Position, Check 17-80
Crankshaft Position, Check 17-84
Engine Coolant Temperature, Check 17-80
Engine Coolant Temperature, Check 13A-937
Engine Coolant Temperature, Check 17-84
Intake Air Temperature, Check 13A-936
Intake Air Temperature, Check 17-79
Intake Air Temperature, Check 17-84
Knock 16-42
Knock, Check 16-35
Manifold Absolute Pressure, Check 17-84
Manifold Absolute Pressure, Check 17-80
Outside Air Temperature 55A-126
Outside Air Temperature 55A-126
Oxygen, Check 13A-937
Wheel Speed 35B-171
Sensor Location 70-6
Shift Switch Assembly
Continuity Check 23A-146
Shock Absorber 34-16
Side Air Dam 51-13
Side Impact Sensor 52B-382
Sight Glass (Refrigerant Level Test) 55A-112
Snap Rings
Adjustment 22B-3
Solenoid
Evaporative Emission Purge, Check 13A-944
Evaporative Emission Ventilation, Check 13A-944
Solenoid Location 70-14
Solenoid Valve Location 70-14
Spacers
Adjustment 22B-3
Spark Plug
Check and Adjustment 16-37
Replace 00-57
Test 16-37
Specifications 34-2
SRS
Circuit Diagram 90-212
SRS Air Bag
Diagnosis 52B-27
SRS Control Unit (SRS-ECU) 52B-364
SRS Warning Light Check 52B-29
Stabilizer Bar 33-19
Stabilizer Bar
GTS, ES 34-20
Starter Motor
Assembly 16-27
Starter Relay
Check 16-26
Starting System 16-23
Starting System
Circuit Diagram
CVT 90-35
M/T 90-34
Diagnosis 16-24
Steering
Adhesive 37-3
Ball Joint Dust Cover Inspection 37-20
Removal and Installation 37-21
Sealant 37-3
Steering Column Shaft Assembly Shock Absorbing Mechanism
Check 37-20
Steering Gear Shaft Assembly 37-25
Steering Linkage Seals
Check 00-67
Steering Wheel 37-21
Steering Wheel
Free Play Check 37-13
Stationary Steering Effort Check 37-15
Steering Angle Check 37-14
Steering Wheel Return to Center Check 37-16
Stoplight
Circuit Diagram 90-98
Switch Check 35A-35
Strut Assembly 33-10
Strut Assembly
Disassembly and Assembly 33-11
Inspection 33-14
Inspection 33-10
Strut Tower Bar 42A-11
Sunroof 42A-218
Sunroof 42A-178
Sunroof
Check 42A-213
Circuit Diagram 90-232
Diagnosis 42A-179
Fit Adjustment 42A-213
Initialized Check 42A-214
Operation Check 42A-215
Safety Function Check 42A-213
Timer Function Check 42A-213
Water Test 42A-212
Suspension System
Inspect for Looseness and Damage 00-67
Switch
Check 00E-10

T

Tension Pulley 55A-128
Theft Alarm 54A-571
Theft-alarm System
Circuit Diagram 90-278
Thermostat 14-18
Throttle Actuator Control Motor
Check 13A-943
Throttle Body
Assembly 13A-950
Cleaning 13A-929
Tie Rod End
Steering, Ball Joint Breakaway Torque Check 37-14
Tightening Specification(s)
Clutch Overhaul 21B-2
CVT Overhaul 23B-3
Engine Overhaul 11B-4
Front Suspension 33-3
Transaxle Overhaul 22B-4
Wheel and Tire 31-8
Tightening Torque 00-48
Timing Chain 11A-63
Tire 31-7
Tire
Diagnosis 31-2
Diagnosis 31-2
Inflation Pressure Check 31-7
Rotation 00-68
Wear Check 31-7
Tire Pressure Monitoring System
Circuit Diagram 90-274
TPMS Transmitter
Removal and Installation 31-7
Trailing Arm 34-12
Trailing Arm
Bushing, Replacement 34-13

Transaxle
Automatic, Fluid Level Check 00-62
Transaxle Assembly 22A-12
Transaxle Control 22A-9
Transaxle Mounting 32-5
Transaxle Oil
Level Check 22A-8
Replacement 22A-8
Transistor 55A-124
Transistor 55A-124
Trims 52A-10
Trouble Code, ABS
Diagnosis 35B-6
Trunk Lid 42A-174
Trunk Lid 42A-171
Trunk Lid
Clearance Adjustment 42A-173
Diagnosis 42A-171
Height Adjustment 42A-173
Trunk Lid Latch
Inspection 42A-176
Trunk Lid Striker
Adjustment 42A-173
Turn Signal Light
Circuit Diagram 90-94

U

Under Cover 51-16
Upper Arm 34-8

V

Vacuum Circuit Diagram 17-73
Vacuum Hose
Check 17-73
Vacuum Hose Routing 17-72
Vacuum Hoses 17-72
Valve
Clearance check and adjust 11A-11
Fuel Tank Pressure Relief 17-87
Fuel Tank Pressure Relief 17-87
Proportioning, Function Test
Vehicles without ABS 35A-24
Valve Stem Seal 11A-38
Vehicle Identification 00-15
Vehicle Identification 00-15
Vehicle Identification Code Plate 00-18
Ventilators 55A-137

W

Water Hose 14-22
Water Pipe 14-22
Water Pump 14-21
Wheel 31-7
Wheel
Balance Accuracy 31-3
Diagnosis 31-2
Diagnosis 31-2
Runout Check 31-7
Wheel Bearing
Play Check 26-8
Wheel Bearing End Play Check 27-5
Wheel Cylinder Assembly
Rear Drum Brake, Disassembly and Assembly 35A-56
Wheel Speed Sensor 35B-171
Wind Noise
How to Locate 42A-134
Window Glass 42A-12
Window Glass
Diagnosis 42A-14
Door, Adjustment 42A-140
Runchannel 42A-164
Windshield 42A-15
Windshield
Wiper and Washer 51-17
Windshield Intermittent Wiper
Volume Check 51-46
Windshield Washer 51-53
Windshield Washer
Diagnosis 51-21
Windshield Wiper 51-47
Windshield Wiper
Diagnosis 51-21
Windshield Wiper and Washer
Circuit Diagram 90-158
Wiper and Washer
Windshield 51-17